

Low-bedding/Wide Loads

FOREST ROAD PROCEDURES #3

These procedures apply to all forest roads in the Kamloops TSA. These procedures do not apply to roads regulated by the Ministry of Transportation and Infrastructure.

DRIVE DEFENSIVELY – EXPECT THE UNEXPECTED

Known Hazards

- | | |
|--|----------------------------------|
| 1. Restricting the road width for other users. | 5. Overhead power lines. |
| 2. Blocking the road when loading and unloading. | 6. Soft shoulders. |
| 3. Meeting other traffic unexpectedly. | 7. Sideswiping other vehicles. |
| 4. Load shifting while travelling. | 8. Hitting a bridge with a load. |

1. All low-bed and wide load (Low-bed) and escort vehicle drivers must be familiar with the Driving Forest Roads (FRP#1) and Radio Calling (FRP#2) Forest Road Procedures.
2. Whenever practical, Low-bed moves should be conducted during times of reduced traffic volumes.
3. When loading or unloading equipment on a haul road, safety triangles, warning signs or flag people must be in place to warn drivers travelling from both directions.
4. Low-bed decks should be kept free of loose objects.
5. All loads must be secured before moving the low-bed.
6. Equipment must never be loaded sideways on the trailer.
7. The following procedures apply to all low-bed moves wider than 10'6" (3.2 meters), outside of an active cut block;
 - a. Loads less than 11'6" wide (3.5 meters)
 - i. Low-bed equipped with either amber rotating lamps or strobes.
 - ii. Headlights and taillights on.
 - iii. Wide load banner or sign.
 - iv. Side marking flags for daylight moves, side marking lights for night moves.
 - b. Loads more than 11'6" wide (3.5 meters)
 - i. All of the requirements from 9(a) above plus;
 - ii. An escort vehicle travelling a sufficient distance in front of the low-bed as to provide ample warning to both the low-bed driver and the oncoming vehicle.
 - iii. The escort vehicle must be equipped with following;
 - a. Either amber rotating lamp or strobe light (temporary mount acceptable).
 - b. 2-way radio on the designated road channel.
 - iv. Must identify themselves as a Wide Load on the radio, i.e. "wide load loaded 225".
 - v. Must call every EVEN "Empty" km and every ODD "Loaded" km/

Follow the "3 C's"	<u>Courtesy</u>	<u>Common Sense</u>	<u>Concentration</u>
---------------------------	------------------------	----------------------------	-----------------------------